

DOZUKI

Ikea

Written By: Brian Sallee



TOOLS:

- [Allen Screws \(4\)](#)
- [Allen Wrench \(1\)](#)




PARTS:

- [Ikea Bernhard Chair \(1\)](#)

SUMMARY

Follow our simple step-by-step guide and your new chair will be fully assembled in minutes!


Step 1 — Getting Started



- Choose a safe location to assemble your Ikea furniture. Avoid surfaces that are slippery or may scratch your chair.
- Your chair comes with 1 allen wrench and 4 allen screws
- fasdjfhj
- asdfhaks
- asdfjkahsd



Step 2 — Let the Assembly Begin




- Slide the Right chair leg into the housing on the bottom of the chair
- Align the screw holes of the chair leg and housing

Step 3



- Align the screw holes by turning the chair leg housing on the bottom of the chair
- Using 2 allen screws, attach the Right chair leg to the housing on the bottom of the chair

Step 4



- Repeat steps 2 and 3 for the left chair leg



Step 5

- Once both chair legs have been tightened by hand, flip the chair over.
- Make sure both legs are flush with a flat surface.
- Using the allen wrench supplied, tighten the screws connecting the chair legs to the housing.



Enjoy your New Ikea Furniture!

This document was last generated on 2012-11-17 04:27:15 PM.